

## General Description

This section covers the instrumentation control unit model 3 (ICU3). It is optional on both the Argosy COE and the Century Class Conventional.

### ICU3

The ICU3 is a basic electronic dashboard that accepts input from the fuel level sensor, the transmission temperature sensor (if installed), and the J1587 datalink. The information is processed by a micro-computer and displayed on electronic gauges driven by stepper motors. Only air gauges operate mechanically.

The following gauges are standard:

- Speedometer
- Tachometer
- Engine Oil Pressure Gauge
- Coolant Temperature Gauge
- Fuel Level Gauge
- Primary Air System Pressure Gauge
- Secondary Air System Pressure Gauge

The transmission fluid temperature gauge is optional, but it is required on vehicles with automatic transmissions.

The speedometer and tachometer are large-faced electronic gauges located below the driver information center. See [Fig. 1](#).




Fig. 1, ICU3

The other gauges are small-faced gauges on the driver's instrument panel, to either side of the speedometer and tachometer. The engine oil pressure, coolant temperature, transmission fluid temperature, and fuel level gauges are electronic; the two system air gauges, primary and secondary, are mechanical.

Only the air pressure gauges are replaceable in the field. The ICU3 can not drive gauges located on the auxiliary instrument panel.

## Dash Message Center

The heart of the ICU3 is the dash message center. It has two parts: a set of 26 warning and indicator lights similar to those found on a conventional light-bar, and a dash driver display screen. The dash driver display screen is a 1-line by 7-character liquid crystal display (LCD) which is normally used to display the odometer reading. In addition, there is a separate voltmeter display underneath the odometer display.

The information that can be provided by the message center includes:

- odometer readings
- a listing of active faults

## Mode/Reset Switch

The mode/reset switch is located on the right-hand side of the instrument cluster, if installed. See [Fig. 2](#).




Fig. 2, ICU3 with Mode/Reset Switch

## General Information

The mode/reset switch is used to scroll through the displays on the driver display screen, and to reset the trip distance and trip hours values to zero.

When the odometer reading is displayed and the parking brake is applied:

- Press the mode/reset switch once to display trip distance.
- Press the mode/reset switch a second time to display trip hours (engine hours).
- Press the mode/reset switch a third time and the SELECT screen and the current units, MI or KM, will display.
- Release the parking brake to return to the diagnostic screen.

To reset trip miles and/or trip hours to zero, press and hold the mode/reset switch for 1 second or longer. To toggle between MI (miles) or KM (kilometers), press and hold the mode/reset switch while in the SELECT screen.

The mode/reset switch can also be used to display complete fault codes for diagnostic purposes. For more information, see [Specifications, 410](#).

## Warning and Indicator Lights

There are spaces on the ICU3 for 26 warning and indicator lights. See [Fig. 3](#) for a typical installation.

There are four rows of lights. The lights in the top row are all optional and may be installed in any order, except for two lights which are typically installed at a fixed position.


- Position 1: Stop Engine Warning (Red)—installed on vehicles with Cummins engines only
- Position 7: Wheel Spin Indicator (Amber)

**NOTE:** Positions 1 through 8 are ground-activated circuits; position 9 is power-activated.

On the other three rows, the lights are installed at fixed positions that do not vary. Some lights are optional; if an optional light is not requested, the position is blank (does not light up).

The following fixed-position lights are standard:

- Check Engine Indicator (Amber)
- Low Engine Oil Pressure Warning (Red)
- High Coolant Temperature Warning (Red)



**Fig. 3, Dash Message Center, ICU3**

- Fasten Seat Belt Warning (Red)
- Left Turn Signal (Green)
- Low Battery Voltage Warning (Red)
- Tractor ABS Indicator (Amber)
- Parking Brake On Warning (Red)

- Recirculated Air Indicator (Amber)
- Low Air Pressure Warning (Red)
- Right Turn Signal (Green)
- High Beams On Indicator (Blue)

The following fixed-position lights are optional:

- Engine Protection Warning (Red)
- Alternator No Charge Indicator (Amber)
- High Transmission Temperature Indicator (Amber)—installed on vehicles with automatic transmissions
- Trailer ABS Indicator (Amber)—installed on vehicles designed to be used with a trailer
- Air Restriction Indicator (Amber)

The following lights are optional and their installed location may vary anywhere in the top row:

- Engine Fan On Indicator (Amber)
- Do Not Shift Indicator (Amber)
- ECAS Failure Warning (Red)
- ECAS Transfer Indicator (Amber)
- Low Washer Fluid Indicator (Amber)
- EBS (Electronic Braking System) Warning (Red)
- Water In Fuel Indicator (Amber)

All light bulbs are replaceable in the field, including gauge light bulbs and warning/indicator light bulbs.

## Principles of Operation

### Ignition Sequence

When the ignition keyswitch is turned on, the ICU3 runs through the ignition sequence. See [Fig. 4](#). If the headlights are turned on, the screen displays the odometer and waits for the ignition to be turned on.

**IMPORTANT:** When the ignition keyswitch is first turned on, all the electronic gauges complete a full sweep of their dials, the warning and indicator lights light up, and the buzzer sounds for three seconds.

The following warning and indicator lights go on during the ignition sequence:

- Low Engine Oil Pressure Warning
- High Coolant Temperature Warning
- Low Air Pressure Warning
- Parking Brake On Warning
- Low Battery Voltage Indicator
- Fasten Seat Belt Warning
- All engine warning lights, including Engine Protection, Check Engine, and Stop Engine (on Cummins only)
- All ABS warning lights, including Wheel Spin, Tractor ABS, and Trailer ABS (if installed)

**NOTE:** Even though the engine and ABS warning lights go on during the ignition sequence, they are not controlled by the ICU3, but by their own system ECU (electronic control unit).

Once the ignition keyswitch has been turned on, the ICU performs a self-test, looking for active faults. During the first half of the self-test, all segments of the display illuminate as follows: "888888.8." During the second half of the self-test, the software revision level is displayed.

If there are no active faults, the screen displays the odometer.

If, however, the ICU3 has received active fault codes from other devices, it displays them, one after the other, until the parking brake is released or the ignition keyswitch is turned off.

The screen displays a code, called the message identifier (MID), indicating the ECU or system that is not functioning properly.

*Example:* If the engine or engine control unit is not functioning properly, the screen displays "ECU 128." For a complete list of possible screen displays, see [Specifications, 400](#).

**NOTE:** If the ICU3 receives a message from an ECU that has not been pre-programmed into the ICU's memory, it displays "SYS MID" instead.

Once the parking brake is released, the ICU3 displays the odometer again.

### Odometer

The odometer is set to display in either miles or kilometers, depending on the primary scale of the speedometer. The legend, either "MI" or "KM," illuminates

## General Information




Fig. 4, ICU3 Ignition Sequence

rates between the odometer and the volts display when the engine is running or the headlights are turned on.

The odometer is a seven-digit display with a decimal point, until the vehicle has traveled 999,999.9 miles or kilometers (km). At one million miles (km), the odometer resets itself to "1000000," without the decimal point, and can continue up to 9,999,999. The odometer only displays significant figures (no leading zeros).

**IMPORTANT:** Although the odometer uses data supplied by the engine ECU to update its count, it keeps its own mileage starting from the zero point, which marks where it was first installed.

## Buzzer

The buzzer sounds during the ignition sequence and whenever one of the following conditions exists:

- The engine oil pressure falls below the preset level, which is 5 to 9 psi (35 to 60 kPa) on most engines.
- The coolant temperature rises above the preset level, which is 215°F (101°C) on Caterpillar and Detroit Diesel engines; 221°F (105°C) on Mercedes-Benz engines; and 220°F (104°C) on Cummins engines.
- The air pressure falls below the preset level, which is 44 psi (300 kPa).

- The parking brake is set with the vehicle moving at a speed greater than 2 miles per hour (3 km/h).

An optional ground-activated buzzer can be controlled by another ECU on the vehicle.

## Instrumentation Control Unit 3 Replacement

## Replacement

The instrumentation control unit model 3 (ICU3) is a self-contained one-piece unit, including housing, gauges, and the dash message center. It is attached to wing panels that are fastened to the dash. See [Fig. 1](#).

Air pressure gauges and light bulbs are the only components that are replaceable in the field. For air pressure gauge replacement, see [Subject 110](#). For light bulb replacement, see [Subject 120](#).

To replace individual switches or flipper valves, see [Section 54.03](#), [Subject 110](#).

NOTE: To remove the auxiliary instrument panel, see [Section 54.03](#), [Subject 100](#).

1. If replacing the ICU, attach a sticker to the driver side door frame indicating the mileage from the driver display, and the date that the ICU is being replaced.

**IMPORTANT:** Before draining the air, it can be helpful to move the adjustable steering column to the lowest possible position.

2. Drain both air systems, primary and secondary.

### CAUTION

**Electronic components of the ICU3 are vulnerable to damage from static electricity. If available, wear a wrist grounding strap connected to a ground in the cab or workbench. If a grounding strap is not available, touch a grounded component immediately before doing any work which could bring a tool or body part in contact with ICU3 circuitry.**

3. Remove the four fasteners from the corners of the bezel attached to the front of the ICU housing. See [Fig. 2](#). Fasteners used on the ICU3 are Torx® T25 dog-point screws. See [Fig. 3](#).

### CAUTION

**Do not forcibly pull the driver's panel from the dash. This may dislodge wires from the harness electrical connectors on the back of the ICU housing and damage the wires, the ICU, or the dash.**

4. Pull the old ICU away from the dash. When removing the old ICU from an Argosy COE, care-

fully work the ICU housing free of the wing panels. Do not remove the wing panels unless they are damaged. Pull the top of the unit towards you until the back of the housing is free, then pull up to remove the rest of the unit.

5. Remove the connectors from the back of the housing.
  - 5.1 From behind the ICU housing, disconnect the two electrical connectors in the center of the housing.

**IMPORTANT:** Bleed off all air before trying to remove the air hoses.

  - 5.2 Disconnect all air hoses. Using a paint pen, mark the hoses for ease of installation.
6. Remove the old ICU from the vehicle. See [Fig. 2](#).
7. Install the new ICU3 on the dash. See [Fig. 2](#).
  - 7.1 Connect the air hoses to the air gauges as marked during removal.
  - 7.2 Connect the two electrical connectors, as removed.
  - 7.3 Install the wing panels, if removed.
  - 7.4 Place the ICU3 in the dash and install the fasteners.
8. Turn on the ignition and test the operation of the new ICU3. All the electronic gauges should make one complete sweep and return to their normal indicating positions; the warning and indicator lights should turn on, then off. Mechanical (air) gauges do not make a sweep.

If any gauges are not working properly, the ICU3 will need to be serviced or replaced.

# 54.20

## Instrumentation Control Unit 3 (ICU3)

### Instrumentation Control Unit 3 Replacement




Fig. 1, ICU3 With Wing Panels




Fig. 2, ICU3 Installation

Instrumentation Control Unit 3 Replacement




Fig. 3, Dog-Point Screw

## Air Pressure Gauge Replacement

## Replacement


**IMPORTANT:** Before draining the air, it can be helpful to move the adjustable steering column to the lowest possible position. This makes it easier to remove the ICU.

1. Drain both air systems, primary and secondary.

**CAUTION**

To avoid damaging the ICU, please read and follow the cautions in [Subject 100](#) regarding grounding the ICU and forcibly pulling it from the dash.

2. Remove the ICU3. See [Fig. 1](#). For detailed instructions, see [Subject 100](#).




**Fig. 1, ICU3**

3. Remove the reset button from the front of the ICU housing, if installed.

**CAUTION**

Use extreme care to avoid breaking the clips when prying them off the ICU housing. The clips are under tension and are easy to damage.

4. Using a thin-bladed screwdriver, very carefully pry off the nine large white clips from the sides of the ICU housing. Remove the bezel from the ICU housing. See [Fig. 2](#).
  - 4.1 From the back of the ICU housing, remove the ferrule from the threaded tube coming out the back of the air gauge.



**Fig. 2, Air Pressure Gauge Installation**

- 4.2 Remove the nut from the threaded air tube.
5. Remove the old air gauge from the ICU.
  6. Install the new air gauge.
    - 6.1 Insert the new gauge into the hole in the ICU housing.
    - 6.2 Tighten the nut on the threaded tube.
    - 6.3 Install the ferrule.
  7. Position the bezel on the ICU housing. Fasten the nine white clips to the sides of the ICU housing.
  8. Install the reset button on the ICU housing, if removed.
  9. Install the ICU3. For detailed instructions, see [Subject 100](#).
  10. Start the engine and wait for the air pressure to build up. When it has, test the operation of the new gauge.

Light Bulb Replacement

Replacement

IMPORTANT: Before draining the air, it can be helpful to move the adjustable steering column to the lowest possible position. This makes it easier to remove the ICU.

1. Drain both air systems, primary and secondary.

**CAUTION**

To avoid damaging the ICU, please read and follow the cautions in **Subject 100** regarding grounding the ICU and forcibly pulling it from the dash.

2. Remove the ICU3. See **Fig. 1**. For detailed instructions, see **Subject 100**.




Fig. 1, ICU3

**CAUTION**

Use extreme care to avoid breaking the clips when prying them off the ICU housing. The clips are under tension and are easy to damage.

3. Pry off the five small black clips from the sides of the ICU housing. Remove the back cover from the ICU housing. See **Fig. 2**.
4. Remove the burnt-out light bulb(s). See **Fig. 3**.
  - 4.1 To remove gauge light bulbs, twist the bulb holder behind the affected gauge until the bulb comes out.
  - 4.2 To remove warning/indicator light bulbs, use a small screwdriver to twist out the bulb base behind the affected light.




Fig. 2, Back Cover Installation




Fig. 3, Light Bulb Installation

5. Install the new light bulb(s).
  - 5.1 To install gauge light bulbs, twist the bulb holder into the slot from which the old one was removed.
  - 5.2 To install warning/indicator light bulbs, insert the new bulb base into the proper slot and use a small screwdriver to tighten it.
6. Position the back cover on the ICU housing. Fasten the five black clips to the sides of the ICU housing.

### Light Bulb Replacement

7. Install the ICU3. For detailed instructions, see [Subject 100](#).
8. Turn on the ignition keyswitch. Check all bulbs for correct operation.

## Fuel Level Gauge Diagnosis

The fuel level gauge is controlled by the ICU using a variable resistance input from the fuel level sending unit that is located in the fuel tank. The fuel level sending unit resistance varies linearly from  $31\pm 2\Omega$  with a full tank to  $247\pm 3\Omega$  when empty.

If the ICU3 is measuring a resistance greater than  $284\Omega$  between circuit 47 and ground, a fault will be set for fuel level circuit open. If the ICU3 is measuring less than  $23.5\Omega$  between circuit 47 and ground, a

fault will be set for fuel level circuit shorted low. ServiceLink may be used to monitor for these faults. The gauge will read empty until the measurement from the sensor is between  $284\Omega$  and  $23.5\Omega$ . Refer to [Table 1](#) for the fuel level diagnostic procedure.

**NOTE:** If the fuel level sensor is below the minimum resistance (short to ground) or above the maximum (open), the fuel gauge will read empty. Shorting the fuel sensor wires will not drive the gauge to full scale.

| Fuel Level Gauge Diagnosis |   |  |  |
|----------------------------|---|--|--|
| Step                       | Test Procedure  | Test Result  | Action   |
| 1                          | <p>If a 100 ohm resistor is available, disconnect the fuel level sender connector and place the resistor across circuit 47 and ground in the wiring harness connector to simulate the fuel level sending unit. Turn the ignition to the ON position and observe the fuel gauge. If, after gauge initialization, the gauge points closely to the half tank mark, then the wiring and ICU are all operating correctly. Jump to Step 4 if there is no problem with the wiring and ICU.</p> <p>Does the fuel level gauge stay at empty even though there is fuel in the tank or is the complaint an inaccurate and intermittent reading?</p> <p>Note - turn the ignition to OFF and disconnect the batteries before continuing.</p> | Stays at Empty                                     | Go to Step 2.  |
|                            |   | Inaccurate or Intermittent                         | Go to Step 4.  |
| 2                          | <p>Disconnect the connector at the fuel level sender and measure the resistance of the sender.</p> <p>What is the resistance of the sender?</p>   | Greater than $284\Omega$ or Less than $23.5\Omega$ | Go to Step 4.  |
|                            |   | Between $284\Omega$ and $23.5\Omega$               | Go to Step 3.  |
| 3                          | <p>Connect the fuel level sender and disconnect the connectors on the back of the ICU. Measure the resistance in the vehicle wiring between circuit 47 in connector pin D1 and the ground circuit in connector pin D2.</p> <p>What is the resistance of the circuit?</p>  | Greater than $284\Omega$                           | Troubleshoot and repair an open circuit on either circuit 47 or the ground between the ICU connector and the fuel level sender.                              |
|                            |   | Between $284\Omega$ and $23.5\Omega$               | This is the valid resistance range. If the fuel tank is full and the resistance is close to $31\Omega$ , replace the ICU. Otherwise no problem is indicated. |
|                            |   | Less than $23.5\Omega$                             | Troubleshoot and repair a short to ground on circuit 47 between the ICU connector and the fuel level sender.   |

### Troubleshooting

| Fuel Level Gauge Diagnosis |   |             |   |
|----------------------------|---|-------------|---|
| Step                       | Test Procedure  | Test Result | Action  |
| 4                          | Remove the fuel sending unit from the fuel tank. Connect an ohm meter to the pins at the fuel level sender connector. Slowly move the level of the float arm from full to empty. See Fig. 1. Does the resistance vary linearly from $31\pm 2\Omega$ to $247\pm 3\Omega$ ? | Yes         | Troubleshoot and repair for corrosion or an intermittent connection in the circuitry between the ICU and the fuel level sender. |
|                            |   | No          | Replace the fuel level sending unit.  |

Table 1, Fuel Level Gauge Diagnosis




Fig. 1, Testing the Fuel Level Sending Unit

The instrumentation control unit model 3 (ICU3) has two pink connectors that plug into pins located in the center of the unit, on the back. Connector #1 has 24 cavities, numbered A1 through A12, and B1 through B12. Connector #2 has 32 cavities, numbered C1 through C16, and D1 through D16.

See **Fig. 1** for a schematic of the wiring and pinout connections for the ICU3.

To fully identify fault codes, see **Section 54.03, Specifications 400**, for a complete list of parameter identifiers (PIDs), sub-system identifiers (SIDs), and failure mode identifiers (FMI).

Wire numbers for optional indicators depend on the option installed. The wire number given applies only to the option listed and will change if a different option is installed at that location. Optional indicator #9 is 12V power-activated; all other optional indicators are ground-activated.

**NOTE:** Do not use reserved pins for testing or programming.

| ICU3 Connector #1 Pin Assignments, Pins A1 Through B12 |   |         |
|--|---|---------|
| Number   | Description   | Wire    |
| A1   | Panel Lights  | 29A     |
| A2   | Reserved  | —       |
| A3   | Low Air Pressure  | 18      |
| A4   | Transmission Temperature (optional; automatic transmission) | 30G     |
| A5   | Air Restriction   | 183A    |
| A6   | Engine Fan On (Optional Indicator 2)                        | To GND* |
| A7   | Do Not Shift (Optional Indicator 3)                         | To GND* |
| A8   | ECAS Failure (Optional Indicator 4)                         | To GND* |
| A9   | No Charge (optional)  | 137     |
| A10  | Reserved  | —       |
| A11  | Reserved  | —       |
| A12  | Headlights (high beams)                                     | 20H     |
| B1   | ECAS Transfer (Optional Indicator 5)                        | To GND* |
| B2   | Reserved  | —       |
| B3   | J1587 Datalink (-)  | 1587-C  |
| B4   | Reserved  | —       |
| B5   | Reserved  | —       |
| B6   | Reserved  | —       |
| B7   | Reserved  | —       |
| B8   | Low Washer Fluid (Optional Indicator 6)                     | 320A    |
| B9   | Reserved  | —       |
| B10  | J1587 Datalink (+)  | 1587+C  |
| B11  | Tractor ABS   | 376L    |
| B12  | Ground-Activated Buzzer (optional)                          | 437Z    |

\* Depends on option installed.

**Table 1, ICU3 Connector #1 Pin Assignments, Pins A1 through B12**

# 54.20

## Instrumentation Control Unit 3 (ICU3)

### Specifications

| ICU3 Connector #2 Pin Assignments, Pins C1 through D16 |  |           |
|--|--|-----------|
| Number   | Pin Assignment                                 | Wire      |
| C1   | EBS Warning (Optional Indicator 8)             | To GND*   |
| C2   | Reserved                                       | —         |
| C3   | Reserved                                       | —         |
| C4   | Reserved                                       | —         |
| C5   | Parking Brake                                  | 125       |
| C6   | Reserved                                       | —         |
| C7   | Reserved                                       | —         |
| C8   | Left Turn                                      | 38L       |
| C9   | Reserved                                       | —         |
| C10  | Recirculated Air                               | 98K       |
| C11  | Wheel Spin (optional indicator 7)              | 376S      |
| C12  | Transmission Fluid Temperature Gauge (-)       | 30G       |
| C13  | Transmission Fluid Temperature Gauge (+)       | 30        |
| C14  | Stop Engine—CUM only (optional indicator 1)    | N16       |
| C15  | Check Engine                                   | C799      |
|  |  | D419      |
|  |  | N25       |
| C16  | Engine Protection (optional; shutdown warning) | C659      |
|  |  | D509      |
|  |  | N01       |
| D1   | Fuel Level (+)                                 | 47        |
| D2   | Fuel Level (-)                                 | 47G       |
| D3   | Panel Light Ground                             | GND1      |
| D4   | Water In Fuel (Optional Indicator 9)           | To Power* |
| D5   | Reserved for J1939 Datalink (+)                | 1939+C    |
| D6   | Reserved                                       | —         |
| D7   | Reserved                                       | —         |
| D8   | Right Turn                                     | 38R       |
| D9   | Reserved for J1939 Datalink (-)                | 1939-C    |
| D10  | EMI Ground                                     | GNDC      |
| D11  | Reserved for J1939 (shield)                    | 1939      |
| D12  | Trailer ABS (optional; trailer only)           | 376F      |
| D13  | Printed Circuit (PC) Board Ground              | GND1      |
| D14  | Battery Power                                  | 437       |
| D15  | Ignition Power                                 | 437A      |

| ICU3 Connector #2 Pin Assignments, Pins C1 through D16 |   |      |
|--|---|------|
| Number   | Pin Assignment                          | Wire |
| D16  | Headlight Power (odometer illumination) | 359  |

\* Depends on option installed.

**Table 2, ICU3 Connector #2 Pin Assignments, Pins C1 through D16**

| Message Identifiers (MIDs) |                                  |              |
|----------------------------|----------------------------------|--------------|
| MID                        | Description                      | Text Message |
| 128                        | Engine Control Unit              | ECU 128      |
| 136                        | Anti-Lock Brakes (ABS)           | AbS 136      |
| 140                        | Instrumentation Control Unit     | ICU 140      |
| 164                        | B-Panel Unit                     | bPU 164      |
| 181                        | Communications Unit—Satellite    | SAT 181      |
| 190                        | Air Conditioning Protection Unit | APU 190      |
| 219                        | Collision Detection Radar        | CdU 219      |
| 231                        | Communications Unit—Cellular     | CEL 231      |
| 232                        | SPACE (Seat Belt Unit)           | SbU 232      |

**Table 3, Message Identifiers (MIDs)**

## Specifications





Fig. 1, ICU3 Pinouts



**Fig. 2, Dash Message Center, ICU3**

**Mode/Reset Switch Functions**

**Mode/Reset Switch Functions**

The mode/reset switch has two functions, push and hold. (1) To scroll between screens, push the switch in and release it. (2) To reset screen data, press the switch and hold it in for at least one second.

Use the following flow charts to cycle through the Mode/Reset switch functions and screens.

- See **Fig. 1** for Mode/Reset Switch Start Sequence.
- See **Fig. 2** for Mode/Reset Switch Trip Screens.
- See **Fig. 3** for Mode/Reset Switch Engine Miles and Service Screens.
- See **Fig. 4** for Mode/Reset Switch Fault Screens.
- See **Fig. 5** for Mode/Reset Switch Service Screens.
- See **Fig. 6** for Mode/Reset Switch Oil Level Screens.
- See **Fig. 7** for Mode/Reset Switch Reset and Toggle Screens.

**Service Interval Tables**

For service interval miles look-up values, see **Table 1**.

For service interval hours look-up values, see **Table 2**.

| Service Interval Distance Settings |       |            |
|------------------------------------|-------|------------|
| Number                             | Miles | Kilometers |
| 16                                 | 8500  | 13685      |
| 17                                 | 9000  | 14490      |
| 18                                 | 9500  | 15295      |
| 19                                 | 10000 | 16100      |
| 20                                 | 11000 | 17710      |
| 21                                 | 12000 | 19320      |
| 22                                 | 13000 | 20930      |
| 23                                 | 14000 | 22540      |
| 24                                 | 15000 | 24150      |
| 25                                 | 16000 | 25760      |
| 26                                 | 17000 | 27370      |
| 27                                 | 18000 | 28980      |
| 28                                 | 19000 | 30590      |
| 29                                 | 20000 | 32200      |
| 30                                 | 21000 | 33810      |
| 31                                 | 22000 | 35420      |
| 32                                 | 23000 | 37030      |
| 33                                 | 24000 | 38640      |
| 34                                 | 25000 | 40250      |

**Table 1, Service Interval Distance Settings**

| Service Interval Distance Settings |       |            |
|------------------------------------|-------|------------|
| Number                             | Miles | Kilometers |
| 1                                  | 1000  | 1610       |
| 2                                  | 1500  | 2415       |
| 3                                  | 2000  | 3220       |
| 4                                  | 2500  | 4025       |
| 5                                  | 3000  | 4830       |
| 6                                  | 3500  | 5635       |
| 7                                  | 4000  | 6440       |
| 8                                  | 4500  | 7245       |
| 9                                  | 5000  | 8050       |
| 10                                 | 5500  | 8855       |
| 11                                 | 6000  | 9660       |
| 12                                 | 6500  | 10465      |
| 13                                 | 7000  | 11270      |
| 14                                 | 7500  | 12075      |
| 15                                 | 8000  | 12880      |

| Service Interval Hours Settings |       |
|---------------------------------|-------|
| Number                          | Hours |
| 1                               | 50    |
| 2                               | 75    |
| 3                               | 100   |
| 4                               | 125   |
| 5                               | 150   |
| 6                               | 175   |
| 7                               | 200   |
| 8                               | 225   |
| 9                               | 250   |
| 10                              | 300   |
| 11                              | 350   |
| 12                              | 400   |
| 13                              | 450   |

**Mode/Reset Switch Functions**

| <b>Service Interval Hours Settings</b> |              |
|--|--------------|
| <b>Number</b>                          | <b>Hours</b> |
| 14                                     | 500          |
| 15                                     | 550          |
| 16                                     | 600          |
| 17                                     | 650          |
| 18                                     | 700          |
| 19                                     | 750          |
| 20                                     | 800          |
| 21                                     | 850          |
| 22                                     | 900          |
| 23                                     | 950          |
| 24                                     | 1000         |

**Table 2, Service Interval Hours Settings**

Mode/Reset Switch Functions




Fig. 1, Mode/Reset Switch Start Sequence

### Mode/Reset Switch Functions




Fig. 2, Mode/Reset Switch Trip Screens

Mode/Reset Switch Functions




Fig. 3, Mode/Reset Switch Engine Miles and Service Screens

## Mode/Reset Switch Functions




Fig. 4, Mode/Reset Switch Fault Screens

Mode/Reset Switch Functions




Fig. 5, Mode/Reset Switch Service Screens

## Mode/Reset Switch Functions




Fig. 6, Mode/Reset Switch Oil Level Screens

Mode/Reset Switch Functions




Fig. 7, Mode/Reset Switch Reset and Toggle Screens