



GROUP 54-01
POWER, CHARGE AND
GROUND CIRCUIT

HIGH-CURRENT FUSE BOX



WARNING

- To prevent possible injury, be sure to disconnect the negative (-) cable of the battery and insulate it with tape before removing high-current fuses. (See Gr54-00A.)

CAUTION


- With the negative (-) cable of the battery connected, some high-current fuses are always under battery voltage. An arc will be generated when any of these high-current fuses is replaced without disconnecting the battery negative cable, and this could cause the related electric devices to be damaged.
- If replace the fuse, remove the high-current fuse box from the vehicle.
- If a fuse blows out, identify and remedy the cause, then replace the fuse.
- Be sure to use the fuse with the specified ampere.

High-current fuse box

Fuse No.	Main load	Capacity
HF01	SAM	140A
HF02	—	—
HF03	SAM	80A
HF04	—	—
HF05	Glow ECU	60A
HF06	Starter relay	40A
HF07	—	—
HF08	Hydraulic unit	50A
HF21	—	—
HF22	SAM	40A
F36	—	—
F37	—	—
F38	—	—
F39	—	—
F40	—	—
F41	Hydraulic unit	30A
F42	—	—
F43	—	—


SAM : Signal detect and actuation modules
 ECU : Electronic control unit

FUSE BOX




<Inside of SAM>

SAM : Signal detect and actuation modules



Removal of spare fuse



WARNING

- To prevent possible injury, be sure to disconnect the negative (-) cable of the battery and insulate it with tape before removing fuses. (See Gr54-00A.)

CAUTION

- If a fuse blows out, identify and remedy the cause, then replace the fuse.
- Be sure to use the fuse with the specified ampere.
- Insert the fuse puller into the gap on the outer side of the fuse holder wall to remove the spare fuse.
Do not force the puller into the gap on the inner side of the fuse holder wall. Doing so will break the SAM and cause malfunctions or a fire.

Fuse box

Fuse No.	Main load	Capacity
F01	Starter	10A
F02	—	—
F03	SRS airbag	10A
F04	Opt (IGN)	10A
F05	Power window (driver's seat side)	30A
F06	—	—
F07	Power window (assistant driver's seat side)	30A
F08	—	—
F09	Meter cluster, diagnosis connector, combination switch	10A
F10	—	—
F11	Blower fan	30A
F12	Audio, cab lamp	15A
F13	Starter switch, ISS ECU (B)	10A
F14	Horn	10A
F15	Audio	10A
F16	Cigarette lighter	20A
F17	Fuel filter	20A
F18	ABS ECU	10A
F19	Engine ECU	15A
F20	ISS ECU (IGN)	10A
F21	—	—
F22	Meter cluster	15A
F23	—	—
F24	—	—
F25	Opt (ACC)	10A
F26	Opt (B)	10A
F27	—	—
F28	Engine ECU	15A
F29	—	—
F30	—	—
F31	Engine ECU	20A
F32	—	—
F33	—	—
F34	Fuel pump	15A

ABS : Anti-lock brake system
 ECU : Electronic control unit
 SAM : Signal detect and actuation modules
 SRS : Supplemental restraint system
 ISS : Idling stop and start system


105 SAM INTERNAL CIRCUIT

(1/2)


SAM: Signal detect and actuation modules

Connector classification

A part of this circuit is omitted.



SAM connector (harness side)




105-C10053SAM-1

(2/2)

A part of this circuit is omitted.

SAM: Signal detect and actuation modules


B40
SAM



*1 : With SRS airbag or ISS
*2 : Except *1

ISS : Idling stop and start system
SRS : Supplemental restraint system

SAM connector (harness side)




105-C10053SAM-2


110 POWER CIRCUIT

Battery → high-current fuse → SAM


ECU: Electronic control unit



SAM
(12V BAT)




SAM connector (harness side)




110 POWER CIRCUIT

SAM
(12V ENG BAT)



SAM connector (harness side)




M E M O


110 POWER CIRCUIT

SAM
(12V BAT) 1/4


T/M: Transmission
PTO: Power take-off
M/V: Magnetic valve




SAM connector (harness side)



SAM
(12V BAT) 2/4




SAM connector (harness side)




110 POWER CIRCUIT

SAM
(12V BAT) 3/4

DPF: Diesel particulate filter
ISS: Idling stop and start system




SAM connector (harness side)



SAM
(12V BAT) 4/4


T/M: Transmission
PTO: Power take-off




110 POWER CIRCUIT

SAM

(Fuse F01 to F09)



SAM connector (harness side)




ECU: Electronic control unit

Dr: Driver's seat side


As: Assistant driver's seat side

SAM
(Fuse F11 to F14)

ECU: Electronic control unit
ISS: Idling stop and start system




SAM connector (harness side)




110 POWER CIRCUIT

SAM

(Fuse F15 to F17)




SAM connector (harness side)




SAM
(Fuse F18 to F20)

ECU: Electronic control unit
ISS: Idling stop and start system




SAM connector (harness side)




110 POWER CIRCUIT


SAM
(Fuse F22)




SAM connector (harness side)



SAM
(Fuse F25, F26)




SAM connector (harness side)




110 POWER CIRCUIT

SAM
(Fuse F28 to F31)


ECU: Electronic control unit




SAM connector (harness side)



SAM
(Fuse F34)




SAM connector (harness side)





115 RESERVE POWER CIRCUIT

ECU: Electronic control unit



SAM connector (harness side)






*1 : With SRS airbag or ISS
 *2 : Except *1


ISS : Idling stop and start system
 SRS : Supplemental restraint system

Meter cluster
C01

Meter cluster connector
 (harness side)




SAM connector (harness side)



130 GROUND





[1] - [2] Cab ground



Location	Circuit No.	Wire diameter - wire color	Destination	Remarks
[1]	EAB2	1.25-B	JOINT (EAB2)	
[2]	EAB3	1.25-B	Frame ground ([12])	

[11] - [16]

Chassis ground



130 GROUND

Location	Circuit No.	Wire diameter – wire color	Destination	Remarks
[11]	HNE1	1.25-B	Frame ground ([12])	Horn
[12]	EAB3	1.25-B	Cab ground ([2])	
	EAC1	1.25-B	JOINT (EAC1)	
	FHE1	1.25-B	Fuel filter	
	FPE1	0.85-B		
	HNE1	1.25-B	Horn ground	
[13]	EAB1	8-B	SAM	
[14]	ABE1	3-B	Hydraulic unit	ABS
	ABE2	3-B		
	EDE1	2.5-B	Engine ECU	
	EDE2	2.5-B		
	EDE3	2.5-B		
	EXE1	1.25-B		
[15]	EAR1	1.25-B	JOINT (EAR1)	
[16]	BTE3	30-BY	Battery	

ABS : Anti-lock brake system





ECU : Electronic control unit

SAM : Signal detect and actuation modules

Entire ground


ECU: Electronic control unit

- This diagram indicates grounding points.
- See the following pages for branching of grounding (wiring for ☆).
(in circuit No. order)




130 GROUND


Circuit No. EAB1 ground (1/6)



SAM connector (harness side)




Circuit No. EAB1 ground (2/6)
 <JOINT(EAB1E)>



*1 : With SRS airbag or ISS
 *2 : Except *1


SAM connector (harness side)




ECU: Electronic control unit
 ISS: Idling stop and start system
 SRS: Supplemental restraint system

130 GROUND


Circuit No. EAB1 ground (3/6)
 <J/C(EAB1LG)>




SAM connector (harness side)



Circuit No. EAB1 ground (4/6)
 <JOINT(EAB1PL)>




SAM connector (harness side)




130 GROUND

Circuit No. EAB1 ground (5/6)
 <JOINT(EAB1PR), JOINT(EAI1)>

ISS: Idling stop and start system
 DPF: Diesel particulate filter
 T/M: Transmission
 PTO: Power take-off




SAM connector (harness side)




Circuit No. EAB1 ground (6/6)
 <JOINT(EAB1S)>

DPF: Diesel particulate filter




SAM connector (harness side)




130 GROUND

Circuit No. EAB2 ground




Circuit No. EAC1 ground

ECU: Electronic control unit
T/M: Transmission
PTO: Power take-off
M/V: Magnetic valve



130 GROUND

Circuit No. EAR1 ground



Circuit No. FPE1 ground

